

Exploded diagram and spare parts hist	(00+70)		1107.1
Machine	Explode	Code	Description
Buffalo 600 Series Under Counter Convection Oven	1_2	AT018	Heater
Buffalo 600 Series Under Counter Convection Oven	3	AT019	Fan Motor
Buffalo 600 Series Under Counter Convection Oven	4	AT020	Fan Blade
Buffalo 600 Series Under Counter Convection Oven	5	AT021	Fan Motor
Buffalo 600 Series Under Counter Convection Oven	6	AT022	Door Seal
Buffalo 600 Series Under Counter Convection Oven	7	AT023	Hinge
Buffalo 600 Series Under Counter Convection Oven	8	AT024	Feet
Buffalo 600 Series Under Counter Convection Oven	10	AT025	Wire Shelf
Buffalo 600 Series Under Counter Convection Oven	11	AT026	Part Of The Hinge
Buffalo 600 Series Under Counter Convection Oven	12	AT027	Door Handle Pipe
Buffalo 600 Series Under Counter Convection Oven	13	AT028	Handle
Buffalo 600 Series Under Counter Convection Oven	14	AT007	Green Signal Lamp
Buffalo 600 Series Under Counter Convection Oven	15	AT014	Red Signal Lamp
Buffalo 600 Series Under Counter Convection Oven	16	AT008	Knob
Buffalo 600 Series Under Counter Convection Oven	17	AT029	50-250 °C Panel Label
Buffalo 600 Series Under Counter Convection Oven	18	AT030	Oven Selection Panel Label
Buffalo 600 Series Under Counter Convection Oven	19	AT031	Thermostat 50-250 °C
Buffalo 600 Series Under Counter Convection Oven	20	AT010	On/Off Switch
Buffalo 600 Series Under Counter Convection Oven	21	AT004	Porcelain Terminal
Buffalo 600 Series Under Counter Convection Oven	22	AT003	Cable Gland
Buffalo 600 Series Under Counter Convection Oven	23	AT002	Supply Cable With EU Plug
Buffalo 600 Series Under Counter Convection Oven	24	AT015	Limit Thermostat 365 °C
Buffalo 600 Series Under Counter Convection Oven	25	AT032	Internal Wiring Group
Buffalo 600 Series Under Counter Convection Oven	26	AT033	Oven Selection Switch Rt.H0S4
Buffalo 600 Series Under Counter Convection Oven	N/A	AP953	Joining Bar