

Exploded diagram and spare parts list (CU474)			Rev.1
Machine	Explode	Code	Description
Buffalo 600 Series Electric Griddle (ribbed plate) 400mm	1	AT001	Heater
Buffalo 600 Series Electric Griddle (ribbed plate) 400mm	2	h	Supply Cable H07RNF 3x1,5 mm <sup>2</sup>
Buffalo 600 Series Electric Griddle (ribbed plate) 400mm	2	AT002	Supply Cable With EU Plug
Buffalo 600 Series Electric Griddle (ribbed plate) 400mm	3	AT003	Cable Gland
Buffalo 600 Series Electric Griddle (ribbed plate) 400mm	4	AT004	Porcelain Terminal
Buffalo 600 Series Electric Griddle (ribbed plate) 400mm	5	AT005	Feet
Buffalo 600 Series Electric Griddle (ribbed plate) 400mm	6	AT006	Logo Buffalo
Buffalo 600 Series Electric Griddle (ribbed plate) 400mm	7	AT007	Green Signal Lamp
Buffalo 600 Series Electric Griddle (ribbed plate) 400mm	8	AT008	Knob
Buffalo 600 Series Electric Griddle (ribbed plate) 400mm	9	AT009	Panel Label 50-300 °C
Buffalo 600 Series Electric Griddle (ribbed plate) 400mm	10	AT010	On/Off Switch
Buffalo 600 Series Electric Griddle (ribbed plate) 400mm	11	AT011	Thermostat 50-300 °C
Buffalo 600 Series Electric Griddle (ribbed plate) 400mm	12	AT012	Waste Oil Container
Buffalo 600 Series Electric Griddle (ribbed plate) 400mm	13	AT013	Internal Wiring Group
Buffalo 600 Series Electric Griddle (ribbed plate) 400mm	14	AT014	Red Signal Lamp
Buffalo 600 Series Electric Griddle (ribbed plate) 400mm	15	AT015	Limit Thermostat 365 °C
Buffalo 600 Series Electric Griddle (ribbed plate) 400mm	N/A	AP953	Joining Bar