

600 Series Chip Scuttle

Instruction manual



Model • Modèle • Modell • Modello • Modelo • Malli: CU479

EN

Safety Instructions

Warning: Incorrect installation, operation, maintenance or cleaning of the equipment, as well as any modification can cause property damage and personal casualty. Fully read and understand all instructions before installation.

- Position on a flat, stable surface.
- A service agent/qualified technician should carry out installation and any repairs if required. Do not remove any components on this product.
- Consult Local and National Standards to comply with the following:
 - Health and Safety at Work Legislation
 - BS EN Codes of Practice
 - Fire Precautions
 - IEE Wiring Regulations
 - Building Regulations
- Switch off after use.



- Caution! Hot surface!
- DO NOT immerse the appliance in water.
- DO NOT clean with jet/pressure washers.
- DO NOT move or carry the appliance when it is switched on.
- **Caution!** Never switch on the chip scuttle without foodstuff in the container.
- ALWAYS ensure to avoid overloading the container. Failure to do so could result in damage or fire.
- ALWAYS use suitable food ingredients.
- Great care must be taken by the operator when using the appliance to guard against any risk of fire.
- During and after use, the unit is still hot. Never touch the surface to avoid scalding.
- Suitable for indoor use only.

- Greasy food waste may spill on the worktop or ground. Wipe away immediately to avoid any injury or damage.
- Keep all packaging away from children. Dispose of the packaging in accordance to the regulations of local authorities.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a danger or injury.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience or knowledge, unless they have been given supervision or instruction concerning the use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Buffalo recommend that this appliance should be periodically tested (at least annually) by a Competent Person. Testing should include, but not be limited to: Visual Inspection, Polarity Test, Earth Continuity, Insulation Continuity and Functional Testing.
- BUFFALO recommend that this product is connected to a circuit protected by an appropriate RCD (Residual Current Device).

Introduction

Please take a few moments to carefully read through this manual. Correct maintenance and operation of this machine will provide the best possible performance from your BUFFALO product.

Buffalo will not accept liability for product failures in the event that:

- The instructions in this manual have not been followed correctly.
- Unqualified or unauthorized personnel have adjusted the appliance.
- Non-original spare parts are used.
- The appliance has not been handled and cleaned correctly.
- The appliance has been used for a purpose for which it was not intended.
- The appliance is used by personnel not trained or unfamiliar with the usage of the unit.

(EN)



Pack Contents

The following is included:

• BUFFALO chip scuttle

• Instruction manual

BUFFALO prides itself on quality and service, ensuring that at the time of unpacking the contents are supplied fully functional and free of damage.

Should you find any damage as a result of transit, please contact your BUFFALO dealer immediately.

Installation

Before installation and operation, it is the user's responsibility to ensure that all Health & Safety regulations concerning safe positioning, spacing, ventilation, electrical installation, and fire risk, are complied with.

- Remove the chip scuttle from the packaging, ensuring that all protective packaging, plastic and residues are thoroughly cleaned from its surfaces.
- Place the unit on a heat-resistant surface. Avoid placing it on or close to flammable materials. Maintain a distance of 20cm (7 inches) between the appliance and walls or other objects for ventilation.
- Keep the unit away from splashing water and countertop's edge.

Note: Before using for the first time, clean all parts well. Let dry completely. Ensure the on/off switch is set to the "0" position.

Operation Off position Off position On position On position On position On position On position On position

- 1. Connect the appliance to a suitable mains power supply.
- 2. Set the on/off switch to the On position. The indicator light illuminates and the appliance begins to heat up.
- 3. After use, set the on/off switch to "0" (Off position) and disconnect the appliance from power supply.

WARNING: The food and appliance are very hot! Take care when removing the foodstuff from the container.

4

Cleaning, Care & Maintenance

- The appliance should be cleaned after each day's operation; however it may require cleaning more often, depending on the volume of use carried out.
- Do not use any abrasive cleaning agents on the appliance.
- 1. Switch off and disconnect the appliance from the power supply.
- 2. Allow the appliance to cool down before cleaning.
- 3. The ceramic heater cannot be immersed in water, but can be wiped down with a damp cloth.
- 4. Use a suitable detergent to clean the container. Let it dry well, ensuring no moisture enters the inside of the appliance.
- 5. The main body can also be cleaned with warm soapy water.
- 6. After cleaning as above, please use a dry cloth to clean the appliance to ensure there is no water on the control panel.

Clean removable parts

- Use warm, soapy water and a soft brush to clean the chip scuttle container.
- Dry thoroughly.

Troubleshooting

A qualified technician should carry out repairs if required.

Fault	Probable Cause	Solution
The unit is not working	The unit is not switched on	Check the unit is plugged in correctly and switched on
	Plug or lead is damaged	Replace plug or lead
	Fuse in the plug has blown	Replace the fuse
	Mains power supply fault	Check mains power supply
Appliance heats up but indicator light does not come on	Indicator light has expired	Consult a qualified technician
On/off indicator	Faulty on/off switch	Consult a qualified technician
light comes on but appliance does not heat up	Faulty heating element	Consult a qualified technician
Appliance overheats	High voltage, improper use	Switch Off immediately. Consult a qualified technician

(EN)

CU479_EN_A5_v1_20231020.indb 6

Technical Specifications

Note: Due to our continuing program of research and development, the specifications herein may be subject to change without notice.

Model	Voltage	Power	Dimensions H x W x D mm	Weight
CU479	230V 1N~, 50-60Hz	1000W	280 x 400 x 600	12kg

Electrical Wiring

(EN)

This appliance is supplied with a 3 pin BS1363 plug and lead.

The plug is to be connected to a suitable mains socket.

This appliance is wired as follows:

- Live wire (coloured brown) to terminal marked L
- Neutral wire (coloured blue) to terminal marked N
- Earth wire (coloured green/yellow) to terminal marked E

This appliance must be earthed.

If in doubt consult a qualified electrician.

Electrical isolation points must be kept clear of any obstructions. In the event of any emergency disconnection being required they must be readily accessible.

Compliance

The WEEE logo on this product or its documentation indicates that the product must not be disposed of as household waste. To help prevent possible harm to human health and/or the environment, the product must be disposed of in an approved and environmentally safe recycling process. For further information on how to dispose of this product correctly, contact the product supplier, or the local authority responsible for waste disposal in your area.

BUFFALO parts have undergone strict product testing in order to comply with regulatory standards and specifications set by international, independent, and federal authorities.

BUFFALO products have been approved to carry the following symbol:

All rights reserved. No part of these instructions may be produced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of BUFFALO. Every effort is made to ensure all details are correct at the time of going to press, however, BUFFALO reserves the right to change specifications without notice.







UK	- 44 (0)94E 146 2997	
Eire	+44 (0)845 146 2887	
NL	040 – 2628080	
FR	01 60 34 28 80	
BE-NL	0800-29129	
BE-FR	0800-29229	
DE	0800 – 1860806	
IT	N/A	
ES	901-100 133	







